


# Operating and maintenance instruction

---

Cutting Head Type XIX 2.0 - PWJ (6200 bar / 90,000 psi)



Operating and maintenance instruction

## General

### **Scope of application**

The present operating and maintenance instruction is valid for following cutting head type XIX 2.0 (6200 bar / 90,000 psi).

- 904200-P
- 904201-P

For abrasive application, the following abrasive cutting heads can be used.

- 950800

Table of contents

---

1	General .....	5
1.1	Information on use of the operation and maintenance instruction .....	5
1.2	Scope of delivery .....	5
1.3	Warranty claim .....	5
1.4	Disclaimer .....	5
2	Security .....	6
2.1	Declaration of symbols .....	6
2.2	General warning notes .....	6
2.3	Intended use .....	7
2.4	Inadmissible usage .....	8
2.5	Residual risks .....	9
2.6	Safety installations .....	10
2.7	Personal protection equipment .....	10
2.8	Qualification of the staff .....	10
3	Structure and function .....	11
3.1	Structure .....	11
3.2	Function .....	12
3.3	Accessories .....	12
4	General technical data .....	13
5	Installation and commissioning .....	14
5.1	Compressed air screw connection orientation .....	16
5.2	Mount cutting head on the machine .....	16
5.3	Flush cutting head .....	17
5.4	Mount Orifice .....	18
5.5	Cutting head function check .....	19
6	Deinstallation .....	19
7	Maintenance, Service and Repair .....	20
7.1	Regular maintenance .....	21
7.2	Replace Orifice .....	21
7.3	Replace collimation tube .....	22
7.4	Replace seal kit and valve seat .....	23
7.5	Adjust the stroke of the pneumatic cylinder .....	25
8	Faults and Troubleshooting .....	27

8.1	Leakage of the cutting head: .....	27
8.2	Further troubleshooting .....	28
9	Recycling .....	28

Appendix A – Technical drawing and parts list (shipped with the product)

## 1 General

### 1.1 Information on use of the operation and maintenance instruction

This operation and maintenance instruction is a key part of the product. The information in this manual is mandatory and must be read and understood by all the persons before operating with the cutting head type XIX 2.0. The manual must be stored in distance as well as always accessible to the persons, working with the cutting head type XIX 2.0.

Should you have any questions regarding the content of the manual, please contact the manufacturer directly.

ALLFI AG - Riedenmatt 1 – CH-6370 Stans  
Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10  
E-Mail: [info@allfi.com](mailto:info@allfi.com) - <http://www.allfi.com>

### 1.2 Scope of delivery

The individual parts contained in the shipment can be gathered from the set list in the appendix A (technical drawing and part list). Upon receipt, the shipment has to be checked of integrity. Possible detected defectives must be reported immediately to the manufacturer.

### 1.3 Warranty claim

The ALLFI AG grants warranty for the shipped parts as followed:

- Material and manufacturer faults of 12 months from date of delivery or
- Defects within the first 2000 hours of operation

Following spare parts are excluded from the warranty:

- Seal Kit
- Valve Seat
- Nozzle
- Collimation Tube
- O-Ring
- Valve Case

### 1.4 Disclaimer

ALLFI AG refuses any claims of liability (material damages, physical injury, as well as disruption of operation), that are a result of disregarding this operating and maintenance instruction.

For example, the damage as a consequence of:

- Inadmissible application of the cutting head
- Defective maintenance
- The disregard of operation instructions
- Chemical and electrolytical influences
- Use of parts, spare parts or accessory from a third-party manufacturer
- Arbitrary modifications
- Not or insufficiently trained staff

The disregard of all these instructions happens on exclusive risk and exclusive responsibility of the client. The ALLFI AG is not liable for any production downtimes.

## 2 Security

### 2.1 Declaration of symbols

This operating and maintenance instruction manual contains important notes and symbols, which are to be considered and followed. These include:



#### **DANGER**

**Danger emphasizes operating and service procedures that if not avoided, may lead to death or serious personal injuries.**



#### **WARNING**

**Warnings emphasize operating or service procedures, or conditions that can result in serious personal injury or death.**



#### **CAUTION**

**Cautions emphasize operating or service procedures, or conditions that can result in equipment damage or impairment of system operation. If not avoided, light or medium body injuries could be the consequence.**

#### **NOTE**

**Notes provide additional information that can expedite or improve operating or service procedures.**



Danger symbol without key word: Additional notes

### 2.2 General warning notes

Using of the cutting head type XIX 2.0, the following warnings are to be considered.



The specified warnings are not only restricted to the operation with the maximal permissible operating pressure of 6200 bar / 90,000 psi. They are also valid on work with reduced operation pressures!

 **DANGER**

**Danger of cutting of extremities on contact with waterjet**

The contact with the high kinetic energy performing waterjet can have the consequence of cutting of extremities or lead to other injuries.



**Therefore:**

- Operate the machine only, when nobody stands in the danger zone of the waterjet.
- Never touch the waterjet, not even with personal protective equipment.
- Always maintain sufficient safety distance during operation of the cutting head.
- Never guide the cutting head by hand during operation.



Any injuries in connection with the waterjet, alarm the emergency doctor immediately.

 **CAUTION**

**Danger of breathing difficulties and irritation of the skin and eyes by released solid particles or dust.**

During machining of certain material, solid particles and dust may float in the air, which could cause breathing difficulties and irritations to the skin and eyes.



**Therefore:**

- Ensure the proper ventilation of the room surrounding the machinery.
- Ensure to wear the personal protective equipment (protection glasses, breathing mask, gloves, ...)



Additionally, the rules and regulations of the working place are to be followed to prevent injuries!

## 2.3 Intended use

The intended use consists in:

- operate the cutting head with air pressure
- switch the cutting head on and off to cut different material
- the fixed installation (no hand guidance) of the cutting head on the machine
- if provisions against flying fragments or a leaking liquid with high pressure are made
- if water is used exclusively as working fluid
- if the technical limit values are respected

## 2.4 Inadmissible usage

Inadmissible usage of the cutting head includes:

- The usage of all other fluids other than water
- The addition of other substances to the water
- Closure of the pressure relief holes
- Manually guide the cutting head by hand
- Excessive application of the cutting head e.g. large fluctuations in pressure
- Exceeding permitted limits
- Operating the valve with demounted or disabled technical protection
- Use the cutting head as a security valve

Likewise, all other uses of the filter deviating from the intended use are not permitted. All questions should be addressed directly to the manufacturer.

ALLFI AG - Riedenmatt 1 – CH-6370 Stans

Tel.: +41 41 618 05 05 - Fax: +41 41 618 05 10

E-Mail: [info@allfi.com](mailto:info@allfi.com) - <http://www.allfi.com>



## 2.5 Residual risks

The manufacturer and/or operator of the machine where the cutting head is built in, has taken every precautionary measure possible to reduce residual risks, as far as possible reasonably practicably.

Operation phase	Damage	Danger	Reason	(possible) measures
Operation	Physical injuries	Liquids leaking under high pressure (e.g. at pressure relief holes)	Ignoring the torque	Follow the torque
			Damaged sealing surfaces	Regular supervision
			Busted/Cracked connections and high-pressure components as a result of defects	
		Flying fragments	Ignoring the torque	Follow the torque
			Damaged sealing surfaces	Regular supervision
			Busted/Cracked connections and high-pressure components as a result of defects	
		Uncontrolled water jet	Spring fracture	Scheduled service (chapter 7)
		High kinetic energy of water jet	Intrusion of extremities in working area of water jet	Technical protective measures or inherently reliable construction of the machine
		High kinetic energy of residual water jet	Cutting of material	Use correctly dimensioned water jet absorber
		Particles of raw material and splash water		Wear protection glasses and personal protection equipment
			Splash-water protection for technical protective measure	
	Hearing damage	Rapidly discharging of fluid		Wear ear protector
				Use correctly dimensioned water jet absorber

## 2.6 Safety installations

The manufacturer or the operator of the full machine, which the cutting head is built in, has ensured the following safety arrangements:

- Protection against intrusion of extremities in working area of water jet
- Safety devices to prevent flying fragments or liquids leaking under high pressure
- Emergency stoppage to immediately shut down the operating machine. This emergency stoppage is an integral part of the system that automatically activates in case of the failure of high pressure components or massive operating errors, alternatively it may be manually activated by the operator.



Danger for the operator will arise if safety protections are not functionally, not followed or evaded anytime. The operator has to ensure the functionality of the safety protections anytime.

## 2.7 Personal protection equipment

The operator must offer his staff following protection equipment while he's working:



Ear protector against:

- Noise emissions

Wear protection glasses against:

- Fluids and dust particles
- Flying fragments

Hand guards against:

- Sharp edges of components
- Intrusion of micro particles into the skin

Inhalation protection against:

- Dust particles, micro particles and spray mist


## 2.8 Qualification of the staff

The cutting head may only be operated and maintained by certified, trained staff.

### 3 Structure and function

#### 3.1 Structure

The cutting head is equipped with a low pneumatic cylinder, therefore the cutting head is ideal for 3D robotic use. The compressed air connection is underneath the cylinder.



Legend:




- 1 Seal Kit 2.0 (1.1 HP-Seal / 1.2 Pressure Plate / 1.3 Needle)
- 2 Pneumatic Cylinder
- 3 Coupling Ring
- 4 Valve Case 2.0
- 5 Valve Seat
- 6 Collar 1/4"
- 7 Gland Nut 1/4"
- 8 Collimation Tube
- 9 Nozzle Cap
- 10 Nozzle

### 3.2 Function

The cutting head opens and closes with a pneumatic piston actuator. The pneumatic pressure in the cylinder lifts the piston against the cylinder springs. The valve needle lifts simultaneous with the piston from the valve seat and opens the water channel. After the compressed air has been released the springs in the cylinder closes the water channel of the cutting head. The compressed air is controlled on and off by a compressed air valve (not included in delivery). The maximal permissible operating water pressure is 6200 bar / 90,000 psi. The operation pneumatic air pressure must be 6 bar / 87 psi ± 0.5 bar / 7 psi anytime.

### 3.3 Accessories

			
Article:	Face Spanner	ALLFI High Tech Paste	Ejector mandrel
Article no:	040006	051005	907224
Function:	Adjust of the stroke	Greasing screw connections and metallic contact areas	Replace Seal Kit and Valve Seat

			
Article:	Torque wrench	Spanner	Molykote DX Paste
Article no:	000468	AF 17 – 000339 AF 18 – 000510 AF 22 – 000272 AF 27 – 000511	051055
Function:	Tightens screws with a specific torque		Greasing screw connections and metallic contact areas

## 4 General technical data

Minimum working pressure:	1500 bar / 22,000 psi
Maximal working pressure:	6200 bar / 90,000 psi
Pneumatic pressure:	6 bar / 87 psi ± 0.5 bar / 7 psi
Maximal working temperature:	50 °C
Maximal stocking temperature:	60 °C
Reaction time:	up to 4 switching cycles per seconds
Weight:	ca. 1.5 kg
Noise emission:	70 – 120dB (a), depends on size of orifice and construction of water jet absorber

### Requested water quality:

Water parameter	Unit	Value
Electrical Conductivity	µS / cm	100 – 450
PH-value	-	7.0 - 8.5
Total hardness	°dH	2.0 - 10.0
Carbonate hardness (acid capacity pH 4.3)	°dH	2.0 - 10.0
Degree of alkalinity pH 8.2	mmol / l	0 - 0.25
Chloride	mg / l	≤ 50
Iron	mg / l	≤ 0.2
Manganese	mg / l	≤ 0.05
Copper	mg / l	≤ 2.0
Silicate	mg / l	≤ 5.0
(Filtrate-) solid content	mg / l	≤ 350

Technical data as dimensions can be found in the technical drawing in appendix A.

## 5 Installation and commissioning

### General installation tip:

- Use of a pneumatic oiler is forbidden.
- Compressed air filter with water separator must be installed.
- Compressed air filter and pneumatic valve must have a minimum nominal flow rate of 5 m<sup>3</sup>/h.
- Absolute cleanliness of the pipes is important before connection.
- A high-pressure filter in front of the cutting head is recommended to extend the service life.
- Follow the steps below for installation.
- Before startup and after inspection or maintenance, check the water tightness of the cutting head.


### WARNING

**Risk of injury: It is forbidden to close the pressure relief holes.**

By closing the pressure relief holes, the cutting head or parts of it may explode.

**Therefore:** Never close or cover any pressure relief hole.

**Positions of the pressure relief holes:**



**NOTE**

**Material damage as a result of pitting**

Not or insufficient greased threads or contact areas can pit.

**Therefore:**

Always grease threads and metallic contact areas with DX-Paste (Article no. 051055). Check appendix A for additional information.

**NOTE**

**Material damage or leakage as a result of fouling**

Fouling components, especially at threads, can lead to leakages and damage.

**Therefore:**

Pay attention to the cleanliness of the components while maintaining.

**NOTE**

**Material damage as a result of leakages**



Constant leakage may damage the product.

**Therefore:**

Immediately eliminate leakages (see chapter 8 „Faults and Troubleshooting“).

## 5.1 Compressed air screw connection orientation

The compressed air screw connection can be switched with the sealing plug.




	<ol style="list-style-type: none"> <li>1. Unscrew compressed air screw connection with open-end wrench AF 13.</li> <li>2. Unscrew sealing plug with hex-wrench 5mm</li> </ol>
	<ol style="list-style-type: none"> <li>3. Mount compressed air screw connection to new position.</li> <li>4. Mount sealing plug to old compressed air position.</li> </ol>

## 5.2 Mount cutting head on the machine



The cutting head can be mounted on the machine in two different ways. Please contact manufacturer for other cutting head mounting options.




During installation, ensure that none of the pressure relief holes are closed!  
Consider flow direction → see appendix A (drawing that is shipped with the product).

	<ol style="list-style-type: none"> <li>1. Unscrew gland nut from coupling ring.</li> <li>2. Remove collar from gland nut.</li> </ol>
	<ol style="list-style-type: none"> <li>3. Slide the gland nut over the HP tube.</li> </ol>
	<ol style="list-style-type: none"> <li>4. Screw the collar on the HP tube (left handed thread). There must be 1 or 2 convolutions visible between the conus and the pressure ring.</li> </ol>



5. Mount cutting head on the machine.	
<b>Screw mounting plate on coupling ring</b>	<b>Mount on collimation tube</b>
 <p>(exemplary drawing)</p>	 <p>(exemplary drawing)</p>
<ul style="list-style-type: none"> <li>➤ Mount cutting head with three M5 screws on machine.</li> </ul>	<ul style="list-style-type: none"> <li>➤ Clamp cutting head on collimation tube to the machine.</li> </ul>

	<ul style="list-style-type: none"> <li>6. Connect the HP tube with the cutting head and tight with the moment of force described in appendix A.</li> <li>7. Mount pneumatic hose.</li> </ul>
---	--

### 5.3 Flush cutting head

**Attention!** Cap must not be installed!

1. Open cutting head by activating the compressed air.
2. Flush cutting head ( $p \leq 500 \text{ bar} / 7,250 \text{ psi}$ ) for 5 to 10 seconds with clean water.

## 5.4 Mount Orifice

### HINWEIS


**Possible damage as a result of direct transfer of the torque to the HP sealing**

The HP sealing will be damaged (pitting on sealing surface) if tight or loosen the cap without holding the collimation tube.

**Therefore:**

Hold collimation tube if tight or loosen orifice cap.



	<ol style="list-style-type: none"> <li>1. Insert orifice in cap as shown. Orifice type see appendix A.</li> </ol>
	<ol style="list-style-type: none"> <li>2. Screw cap on collimation tube and tight according appendix A. <b>Attention!</b> Hold collimation tube if tight or loosen orifice cap.</li> </ol>

## 5.5 Cutting head function check



### DANGER

#### **Danger of cutting of extremities on contact with waterjet**

The contact with the high kinetic energy performing waterjet can have the consequence of cutting of extremities or lead to other injuries.

#### **Therefore:**

- Operate the machine only, when nobody stands in the danger zone of the waterjet.
- Never touch the waterjet, even with personal protective equipment.
- Always sufficient safety distance during operation of the cutting head.
- Never guide the cutting head by hand during operation.

Mount cutting head on the machine and operate the cutting head with operating pressure (water pressure = operating pressure) 5-10 times. Check following points:


- The cutting head opens and closes faultless
- The cutting head operates promptly (no time lag)
- Quality of the waterjet
- Cutting head tightness

If all checked points above are ok, the cutting head will be ready for operation. Please see chapter 8 (Faults and Troubleshooting) for fault diagnostics.

## 6 Deinstallation



Before uninstalling the cutting head, release pressure from the HP tubes and protect against unexpected re-pressurizing.



1. Remove pneumatic hose.
2. Remove HP tube.

Unmount the cutting head from the machine

## 7 Maintenance, Service and Repair

It's not necessarily to unmount the cutting head from the machine. Usually the maintenance is easier if the HP tube is removed and the cutting head is unmounted from the machine.

All maintenance, service and repair work not written in this document has to be executed by the manufacturer. Especially service at the cylinder.

### NOTE

#### Material damage or leakage as a result of fouling

Dirty components, especially considering the threads, may lead to leakages and damage of the cutting head.

**Therefore:**

Ensure a proper cleaning of the components.

### NOTE

#### Possible damage as a result of direct transfer of the torque to the HP-tube

Loosening or tightening the cap (pos. 9 on page 10) without holding the collimation tube can lead to damages on the HP tube connections

Loosening or tightening the collimation tube (pos. 5 on page 10) without holding the valve case can lead to damages on the HP tube connections

**Therefore:**

Hold collimation tube when loosening or tightening the cap (pos. 9 on page 10) with an open-end wrench.

Hold valve case when loosening or tightening the collimation tube (pos. 5 on page 10) with an open-end wrench.

### NOTE

#### Property damage as a result of pitting

Threads that are not greased or insufficiently greased may pit.


**Therefore:**

Always grease threads and metallic contact areas with DX-Paste (Article no. 051055). Check appendix A for additional information.




## 7.1 Regular maintenance

What	By whom	When
Replace disc springs and O-rings in pneumatic cylinder	Service ALLFI AG	All 2,000 operation hours / 1 million. Cycles of operation
Check stroke	Operator	All 500 operation hours / 100,000 Cycles of operation
Check tightness	Operator	Continuous
Check water jet quality	Operator	Continuous
Check rubber cap for any damage	Operator	Continuous

## 7.2 Replace Orifice




1		<ol style="list-style-type: none"> <li>1. Unscrew cap from collimation tube <b>Attention!</b> Hold collimation tube.</li> <li>2. Remove orifice from cap.</li> <li>3. Clean cap and sealing surface of collimation tube.</li> </ol>
2		<ol style="list-style-type: none"> <li>1. Insert orifice according illustration. Type of orifice check appendix A</li> </ol>
3		<ol style="list-style-type: none"> <li>4. Screw cap on the collimation tube and tighten the cap with a torque wrench (moment of force according appendix A) <b>Attention!</b> Hold collimation tube</li> <li>5. Mount cutting head on the machine.</li> <li>6. Cutting head function check (chapter 5.5).</li> </ol>






### 7.3 Replace collimation tube

<p>1</p>		<ol style="list-style-type: none"> <li>1. Pressurize pneumatic cylinder with compressed air (6 bar). The cutting head is now open and the valve seat will not be damaged.</li> <li>2. Remove cap with orifice from collimation tube. Hold collimation tube.</li> </ol>
<p>2</p>		<ol style="list-style-type: none"> <li>1. Unscrew collimation tube from valve case. Hold on valve case AF 27.</li> <li>2. Remove valve seat from old collimation tube and mount in new collimation tube with the same direction.</li> <li>3. Screw and tighten the new collimation tube with a torque wrench (moment of force according appendix A). Hold on valve case AF27.</li> </ol>
<p>3</p>		<ol style="list-style-type: none"> <li>1. Mount cap with orifice on collimation tube according chapter 7.2.</li> <li>2. Mount cutting head on machine.</li> <li>3. Cutting head function check (chapter 5.5).</li> </ol>



## 7.4 Replace seal kit and valve seat

It is necessary to unmount the cutting head from the machine to replace the seal kit and the valve seat.

1		<ol style="list-style-type: none"> <li>1. Remove cap with orifice from collimation tube. Hold collimation tube.</li> <li>2. Pressurize pneumatic cylinder with compressed air (6 bar). The cutting head is now open and the valve seat will not be damaged.</li> </ol>
2		<ol style="list-style-type: none"> <li>1. Unscrew the collimation tube from the valve case. Hold on valve case AF 27.</li> <li>2. Interrupt the compressed air and remove the pneumatic hose from the cylinder.</li> </ol>
3		<ol style="list-style-type: none"> <li>1. Remove the valve seat from the collimation tube. Note the orientation of the valve seat.</li> <li>2. If the orientation of the valve seat is according picture A: - Turn the valve seat and mount it according picture B.</li> <li>3. If the orientation of the valve seat is according picture B: - Replace valve seat and mount it according picture A.</li> </ol>

4		<ol style="list-style-type: none"> <li>1. Clamp pneumatic cylinder at the width across flats in a bench vise. <b>Attention!</b> Do not over tighten, this would deformate the cylinder. Use protective jaws.</li> <li>2. Unscrew valve case at the AF 27.</li> </ol>
5		<ol style="list-style-type: none"> <li>1. Sit valve case on a solid surface according illustration (needle point face up).</li> <li>2. Press the seal kit with the ejector mandrel out of the valve case.</li> <li>3. Dispose/recycle the old seal kit.</li> </ol>
6		<ol style="list-style-type: none"> <li>1. Grease the new seal kit according appendix A.</li> <li>2. Insert new seal kit in pneumatic cylinder.</li> </ol>
7		<ol style="list-style-type: none"> <li>1. Screw and tighten valve case (AF27) on pneumatic cylinder with a torque wrench (moment of force according appendix A).</li> </ol>
8		<ol style="list-style-type: none"> <li>1. Pressurize pneumatic cylinder with compressed air (6 bar). The cutting head is now open and the valve seat will not be damaged.</li> </ol>




<p>9</p>		<ol style="list-style-type: none"> <li>1. Screw collimation tube with valve seat (from step 3) in valve case with a torque wrench (moment of force according appendix A). Hold on valve case AF27.</li> </ol>
<p>10</p>		<ol style="list-style-type: none"> <li>1. Interrupt the compressed air and remove the pneumatic hose from the cylinder.</li> <li>2. Mount cap with orifice on collimation tube according chapter 7.2.</li> </ol>


11. Adjust stroke of the pneumatic cylinder (chapter 7.5).

12. Mount cutting head on the machine.

13. Cutting head function check (chapter 5.5).

## 7.5 Adjust the stroke of the pneumatic cylinder

<p>1</p>		<ol style="list-style-type: none"> <li>1. Clamp pneumatic cylinder at the width across flats in a bench vise. <b>Attention!</b> Do not over tighten, this would deformate the cylinder. Use protective jaws.</li> <li>2. Remove rubber cap.</li> </ol>
----------	---	--

<p>2</p>		<ol style="list-style-type: none"> <li>1. Measure the distance between cylinder cover and piston = <math>X_1</math>.</li> <li>2. Pressurize pneumatic cylinder with compressed air (6 bar).</li> <li>3. Measure the distance between cylinder cover and piston = <math>X_2</math>.</li> <li>4. Adjust stroke with a face spanner: Currently adjusted stroke <math>X_{stroke} = X_1 - X_2</math> Target value <math>X_{stroke,tar} = 0.7 \text{ mm} \pm 0.1 \text{ mm}</math> <ul style="list-style-type: none"> <li>➤ Reduce stroke: turn pneumatic cylinder cover in clockwise direction.</li> <li>➤ Increase stroke: turn pneumatic cylinder cover in counterclockwise direction.</li> <li>➤ One full turn (<math>360^\circ</math>) equates 1.5mm stroke difference.</li> </ul> </li> <li>5. Verify stroke by remeasure.</li> <li>6. Mount rubber cap.</li> </ol> <p><b>Attention!</b> The pneumatic cylinder must be pressurized during the adjustment of the cylinder. If the pneumatic cylinder is not pressurized, the needle or the valve seat will be damaged!</p>
<p>3</p>		<ol style="list-style-type: none"> <li>1. Mount cutting head on the machine.</li> <li>2. Cutting head function check (chapter 5.5).</li> </ol>


## 8 Faults and Troubleshooting



Before uninstalling the cutting head, release pressure from the HP tube and protect against unexpected re-pressurizing.

**Warning!** After any troubleshooting, cutting head function check (chapter 5.5).

### 8.1 Leakage of the cutting head:



Pos. of the leakage	Cause of the leakage	Action	Chapter
<b>1</b> Seal kit (Check twice if the leakage is not at position 2)	HP-Sealing damaged	Replace seal kit	0
	Seal cone in valve case or Pressure Plate damaged	Replace damaged parts	
	Wrong moment of force for the pneumatic cylinder	Use correct moment of force according appendix A	
	Water pressure to high	Please note operating limits	
<b>2</b> HP screw connection	Wrong moment of force for HP screw connection	Tight HP screw connection according appendix A	
	Seal cone of HP tube damaged	Recut the cone of the HP tube	

<b>3</b> Seal cone valve case – valve seat	Wrong moment of force for collimation tube	Tight collimation tube according appendix A	0
	Seal cone damaged	Replace valve seat and/or valve case	7.4
<b>4</b> Seal cone valve seat – collimation tube	Wrong moment of force for collimation tube	Tight collimation tube according appendix A	7.3
	Seal cone damaged	Replace valve seat and/or collimation tube	7.3 / 7.4
<b>5</b> Seal cone collimation tube – orifice	Wrong moment of force for orifice cap	Tight cap according appendix A	7.2
	Seal cone damaged	Replace orifice and/or collimation tube	
<b>6</b> Seal cone valve needle – valve seat	Debris in valve seat	Remove valve seat	7.4
	Seal cone damaged	Replace seal kit and/or valve seat	
	Wrong pneumatic cylinder stroke	Adjust pneumatic cylinder stroke	7.5
	Water pressure to high	Please note operating limits	
	Broken disk springs	Repair cutting head by manufacturer	

## 8.2 Further troubleshooting

Error	Possible causes
Cutting head doesn't open	To low air pressure
	Orifice blocked
Cutting head doesn't close properly / completely	Water pressure to high
	Broken disk springs
	Valve seat or valve needle damaged
	Debris in valve seat
Insufficient water jet quality	Debris in orifice or damaged orifice
	Wrong water pressure

## 9 Recycling

The cutting head is made of metal and plastic. All the metal parts can be recycled. The plastic parts are to be professionally recycled as per local specifications.